



MYREVEST  
PURE ELEGANCE

# MYREADYGO!

## STEP BY STEP

01

### CLEAN THE SURFACE TO BE APPLIED

For an optimum result it is essential that the surface is free of dust and grease.

After cleaning, take the protective tape and mark out the surface to be applied.

\*Important: if the substrate is not stable and/or shows cracks or chipping, repair.  
If there is excessive moisture on the substrate, remedy.

02

### JOINT/JOINTLESS SURFACES

02A) Surfaces without joints (plasterboard, plaster, etc.): Apply one layer of **MyPrimer300**. Wait approximately 30 minutes for it to dry and clean the roller immediately to extend its life.

02B) Surfaces with joints (marble, terrazzo, etc.): Fill the surface joints with a layer of **MyJointer** with the help of a spatula or trowel. Wait 24 hours for drying. Then sand the surface with **40 grit sandpaper**.

It is time to prepare the surface to ensure that the microcement adheres well. And for that, we have **MyPrimer300**.

Use the spatula to manually remove the product. Take the roller and apply a layer of **MyPrimer300**. Wait 2-4 hours for it to dry and clean the roller with water immediately after use to extend its life.

03

### APPLY MYREADYGO! 03

Stir with the help of the **MyReadyGo!03** spatula. Dip the roller in **MyReadyGo!03** and spread the microcement in a layer less than 1 mm thick! Apply **MyReadyGo!03** first vertically and then horizontally. Then smooth with the trowel at an angle of 45° in an arc and in all possible directions. Repeat until the surface is smooth. Apply 2 layers with a roller and trowel and remove the masking tape. Allow 6 hours between each layer to dry thoroughly.

Sand after each layer with **40 grit sandpaper**.

04

### APPLY MYREADYGO! 01

Replace the protective tape. Do the same process and spread the **MyReadyGo!01** in ultra thin layers (less than 0.5mm) with the roller and trowel. Apply 2 layers in total.

Remove the tape and allow 6 hours drying time between layers.

Sand after each layer with **220 grit sandpaper**.

05

### APPLY THE VARNISH

Choose the **MySealantGo!** finish (matt or satin), which will adequately protect the surfaces.

24h after applying the last layer of **MyReadyGo!01**, place the adhesive tape on the surface. Apply 3 layers of **MySealantGo!** in one day and allow 4 hours drying time between each layer.

For extra protection: apply 4 layers in wet areas such as bathrooms and/or floors with high traffic.

We recommend sanding the first and second layers with **400 grit sandpaper**.

\*Important: We recommend waiting 7 days for the varnish to reach its maximum performance.

\*\*All sanding grits indicated in this step-by-step is for hand sanding (not machine sanding).

### Icon guide



Trowel



Roller



MyReadyGo!  
Roller



Sandpaper



Adhesive tape



MYREVEST  
PURE ELEGANCE

# MYREADY

# GO!

